

E-CIGARETTE VAPE KIT

USER MANUAL

Model No: 114098

PLEASE READ THE INSTRUCTIONS CAREFULLY BEFORE USE.

rotate it clockwise to

tighten fully. Before

reattaching the mouth

piece turn the device

upside down, then secure

rotating it anti-clockwise.

Care should be taken not

to over tighten the mouth

piece.

• Turn the Ibiza Club® device upside down, this will

• Open the clearomizer by rotating the mouth piece

• Carefully dispose of any remaining E-Liquid in the


• Do not wash the coil. Wipe clean with dry tissue.

stop any remaining E-Liquid spilling out of the

• Remove the coil by rotating it anti-clockwise.

section below the metal ring clockwise.

the mouth piece section by



FILLING INSTRUCTION

For best results we recommend that you use our specially formulated Ibiza Club® E-liquids with your Ibiza Club® device.


Turn the Ibiza Club® device upside down, this will stop any remaining E-Liquid spilling out of the chamber once open.



To open the clearomizer rotate the mouth piece section below the metal ring clockwise.



Fill the glass chamber with E-Liquid, be careful not to overfill the chamber. E-Liquid should not be poured into the central column.



Close the clearomizer by rotating the mouth piece section anti-clockwise. Care should be taken not to over tighten.

Caution - Some E-Liquids may erode the rubber seals over time. Avoid leaving E-Liquids in the chamber for prolonged periods of time.


USER INSTRUCTION

Caution - Before turning ON the Ibiza Club® device ensure the clearomizer has been filled with E-Liquid. If the clearomizer is activated without any E-Liquid it will cause dry burning damage to the coil.

We recommend allowing the device to stand for approximately 10 minutes once filled with E-Liquid to allow the coil to prime.

Turning ON/OFF

- To turn ON the Ibiza Club® device press the fire button 5 times within 2 seconds. The LED ring around the fire button will flash 3 times once the fire button has been pressed 5 times.
- The Ibiza Club® device is now ON. Pressing and holding the fire button will activate the clearomizer.
- To turn OFF the Ibiza Club® device press the fire button 5 times within 2 seconds. The LED ring around the fire button will flash 3 times once the fire button has been pressed 5 times.
- The Ibiza Club® device is now OFF.



Using the Device

- Ensure the clearomizer has been filled with E-Liquid before pressing the fire button.
- Press the fire button to activate the clearomizer. The LED ring around the fire button will light up when the clearomizer is active.
- Inhale slowly.
- For safety reasons the device will automatically cut off after 10 seconds of pressing the fire button.

REPLACING THE CLEAROMIZER COIL

The coil is a consumable part and should be changed regularly depending upon rate of use. You should

replace the coil if you notice a deterioration in performance, taste or quality.

*Only use Ibiza Club® E-Cigarette replacement coils (Model No: 114128) with this Ibiza Club® device.


Ensure the Ibiza Club® device is turned OFF. Once actioned turn the device upside down, this will stop any remaining E-Liquid spilling out of the chamber once opened.



section below the metal

ring clockwise.

To remove the used coil rotate it anti-clockwise.



CLEANING

chamber once opened.

clearomizer chamber.

 Carefully wash the remaining clearomizer components with warm water and wipe dry with a soft • Replace the coil and secure in place by rotating Insert the new coil and

- clockwise.
- Turn the Ibiza Club® device upside down.

• Do not remove the wick from the coil.

• Replace the clearomizer by rotating anti-clockwise.

DO NOT WASH OR SUBMERGE THE BATTERY IN WATER, WIPE CLEAN WITH A DRY CLOTH.

- Turn the Ibiza Club® device upside down, this will stop any remaining E-Liquid spilling out of the chamber if the clearomizer is opened by mistake.
- The battery is located above the metal ring, to access grip the metal ring and rotate the battery anti-clockwise.
- Connect the battery to the charging cable and then rotate clockwise to secure in place.
- Connect the charging cable to a mains charger or appropriate power source via its USB socket.
- The LED on the charging cable will display red when charging, changing to green when the battery is fully charged.
- Once fully charged detach the battery from the power supply.
- Never leave the battery unattended whilst on

Charging time: Approximately 2.5 hours.

STORAGE

Store below 25°C in a clean dry place. Keep the device out of the reach of children and animals.

PRECAUTIONARY STATEMENTS

READ ALL INSTRUCTIONS AND CARE DETAILS PRIOR TO USING THE DEVICE. IMPROPER USE CAN RESULT IN DEVICE DAMAGE OR MALFUNCTION.

Only use Ibiza Club® replacement coils (Model No. 114128)

- Do not leave this device in direct sunlight or near heat sources.
- Avoid dropping, knocking, scratching or other impacts to the device. In the event of any damage for whatever reason, discontinue use and dispose of the device in a responsible manner.
- Do not attempt to repair or modify this device.
- Keep this device dry at all times other than when cleaning the clearomizer. Do not submerge the battery in liquid or expose to moisture.
- Your Ibiza Club® device has been quality checked after manufacture, however if your battery displays excessive heat or any abnormal phenomenon, discontinue use and dispose of the device in a responsible manner.
- It is recommended that the device is stored charged if it is not intended to be used for an extended period of time.

- Never leave the battery unattended whilst on
- To avoid the risk of injury, fire or damage to the device or property, only charge the device using the charging cable provided.

WARNINGS AND PRECAUTIONS

This product is not recommended for:-

- Non-smokers.
- Young persons under the age of 18 years.
- Pregnant or breast feeding women as nicotine is known to cross the placenta and be excreted in breast
- Persons experiencing general ill health such as heart disease, liver or kidney problems, stomach and duodenal ulcers, long term throat disease or difficulty breathing due to asthma, bronchitis or emphysema.
- Those who have an overactive thyroid gland or have a phaeochromocytoma (a tumour of the adrenal gland that can affect high blood pressure).
- Those who have diabetes, as nicotine can affect your blood sugar levels.
- Those taking the following medication:-Theophylline - to treat breathing problems. Ropinirole - to treat restless legs. Clozapone - to treat schizophrenia.
- Do not use nicotine containing E-Liquids if you are allergic to nicotine or any other ingredient contained in E-Liquids.

Keep out of reach of children.

POSSIBLE SIDE EFFECTS

Inhaling too much nicotine or overuse of the device could lead to you experiencing side effects such as:-

- Nausea, vomiting
- Headache
- Feeling faint Dizziness
- Coughing
- Mouth or throat irritation
- Stomach discomfort
- Nasal congestion
- Hiccups
- Chest palpitations or abnormal heart rate

Discontinue use if you experience any of the above side effects including any other side effects. If side effects persist after discontinuing use, consult your doctor or healthcare professional and bring this leaflet to their attention.

ADDICTIVENESS

Nicotine is highly addictive and is therefore intended for adult smokers only.



To view the full range of Ibiza Club® products visit our website ibizavapeclub.com FIND US and JOIN THE CLUB! #ibizavapeclub @ibizavapeclub



PRODUCED BY: AFB PLC, UNIT 2, ALBAN PARK, HATFIELD ROAD, ST ALBANS, HERTS, AL4 0JJ, UK

MADE IN CHINA

THE NAME IBIZA CLUB® IS A REGISTERED